


Pre-Layout Analysis

Lab 5

- Pre-Layout Signal Integrity Analysis






Lab 5: Pre-Layout Signal Integrity Analysis

HyperLynx LineSim is a pre-layout PCB design simulation and analysis tool that enables you to evaluate the signal integrity performance of signal nets. In this exercise, you will experience the process of selecting a net for simulation, reviewing Simulation Models assigned in PADS Schematic Design environment, selecting a net for analysis, perform an analysis and save the analysis results for future use.

LineSim Link

LineSim Link can export a net to HyperLynx LineSim for pre-layout simulation.

- 1 In PADS Schematic Design environment select **File > Open > Project** and select **E:\PADS_ES_Evaluation\Lesson10\Lesson10.prj**.
- 2 In the Project Navigator, double-click the **Lesson 10** board, then double-click the **CORPORATE** schematic to display the list of schematic sheets.
- 3 Now double-click the **Memory** schematic sheet in the Project Navigator.
- 4 Zoom to the upper left IC shown on the **Memory** sheet. Select the IC **U15**.
Note: Set the **Selection Filter**  to **Symbol** if necessary.
- 5 In the **Properties** window, review the assigned Simulation IBIS models: **SIM_MODEL** and **SIM_MODEL_FILE**. (You may need to scroll down to see them).
Note: If the Properties Window is not visible, click the Properties icon  on the View toolbar.




The screenshot displays the PADS Schematic Design environment. The Project Navigator on the left shows the hierarchy: Lesson10 > Boards > Lesson10 > CORPORATE > Memory > Symbols. The Properties window is open, showing the properties for component U15. The schematic diagram on the right shows IC U15 with various address and data buses connected to it.

Property	Value
Name	
Id	\$4150
Partition	CorporateDemo
Symbol Name	flash_128k.1
Name Inverted	False
Forward To PCB	Inherit From Definition
COST	0.45
Cell Name	SO32M1
DXDB_LIBNAME	ICS
Description	32PIN, 5.5V, FLASH_128K
GEOMETRY.HEIGHT	15.00MIL
Level	STD
MANUFACTURING_BIN_NUMBE	20-33-9994-IC
MANUFACTURING_COMPONENT	+2WEEKS
PARTS	/
PART_NUMBER	S04_5.5V_IC
PRIMARY_MFG	INTEL
Part Label	FLASH_128K
Part Name	FLASH_128K
Part Number	FLASH_128K
Ref Designator	U15
SECONDARY_MFG	HO TOROLA
SIM_MODEL	M74LCX125
SIM_MODEL_FILE	M74LCX125.ibs
Signal	GND;16
Signal	VDD;32
Tolerance	0%
Value	128K_FLASH
Voltage	5.5V

Post-Layout Analysis

Lab 12

- Signal Integrity Analysis




Lab 12: HyperLynx BoardSim Simulation

This exercise will walk you through the process of sending a finished design from PADS Layout to HyperLynx BoardSim and selecting a net for simulation. We will also compare the simulation results with the pre-layout stage that we prepared earlier in LineSim.

HyperLynx BoardSim


- 1 In PADS Layout, select **File > Open** and open **E:\PADS_ES_Evaluation\Lesson29\Lesson29.pcb**.
- 2 Select **Tools > Analysis > Signal/Power Integrity ...**
- 3 In the BoardSim dialog, enable the **.REF IC Automapping file** option, then select the radio button next to **Export pour and plane outlines** and finally select the **OK** button. This will extract all of the data and load design into HyperLynx. When prompted with the **Missing Height** dialog, enable the **For All Parts** option checkbox and click **OK**.
- 4 In HyperLynx BoardSim select the **NET** button.
- 5 In the **Select Net by Name** dialog, scroll down and select **DATA_BUS0** net and then click the **OK** button. This will only show that specific net routed on the board.



Post-Layout Analysis

Lab 13

■ Thermal Analysis





Lab 13: HyperLynx Thermal Analysis

This exercise will walk you through the process of sending a finished design from PADS Layout to HyperLynx Thermal for evaluating any possible heat problems and possible solutions to eliminate excessive heat areas. This exercise does not cover all of the aspects of the HyperLynx Thermal software but highlights a few important features.

HyperLynx Thermal Analysis

This section will demonstrate how to perform a HyperLynx Thermal simulation.

- 1 In PADS Layout, select **File > Open** and select **E:\PADS_ES_Evaluation\Lesson30\Lesson30.pcb**.
- 2 We need to pour Copper and Split/Mixed planes before we transfer the design to HyperLynx Thermal. Select **Tools > Pour Manager** and in the Flood tab, select **Flood All**. Then click the **Start** button. Now select the **Plane Connect** tab and click the **Start** button (if any warning messages about missing thermal connections come up, please ignore). **Close** the Pour Manager window.
- 3 Select **Tools > Analysis > Thermal Analysis**.
- 4 In the **Missing Height** dialog, enable the check box **For All Parts**, then click **OK**. This will extract all of the data and load design into HyperLynx Thermal.
- 5 In HyperLynx Board Sim, if prompted by the Restore Session Edits dialog, click OK, then in the Thermal Sim window select the **Run Thermal Simulation**  icon.
Note: Some components are running hot at 113degC. We will try to resolve two component problems.



This document is for information and instruction purposes. Mentor Graphics reserves the right to make changes in specifications and other information contained in this publication without prior notice, and the reader should, in all cases, consult Mentor Graphics to determine whether any changes have been made.

The terms and conditions governing the sale and licensing of Mentor Graphics products are set forth in written agreements between Mentor Graphics and its customers. No representation or other affirmation of fact contained in this publication shall be deemed to be a warranty or give rise to any liability of Mentor Graphics whatsoever.

MENTOR GRAPHICS MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.

MENTOR GRAPHICS SHALL NOT BE LIABLE FOR ANY INCIDENTAL, INDIRECT, SPECIAL, OR CONSEQUENTIAL DAMAGES WHATSOEVER (INCLUDING BUT NOT LIMITED TO LOST PROFITS) ARISING OUT OF OR RELATED TO THIS PUBLICATION OR THE INFORMATION CONTAINED IN IT, EVEN IF MENTOR GRAPHICS HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

U.S. GOVERNMENT LICENSE RIGHTS: The software and documentation were developed entirely at private expense and are commercial computer software and commercial computer software documentation within the meaning of the applicable acquisition regulations. Accordingly, pursuant to FAR 48 CFR 12.212 and DFARS 48 CFR 227.7202, use, duplication and disclosure by or for the U.S. Government or a U.S. Government subcontractor is subject solely to the terms and conditions set forth in the license agreement provided with the software, except for provisions which are contrary to applicable mandatory federal laws.

© 2014 Mentor Graphics Corporation

Contractor/manufacturer is:

Mentor Graphics Corporation

8005 S.W. Boeckman Road, Wilsonville, Oregon 97070-7777.

Telephone: 503.685.7000

Toll-Free Telephone: 800.592.2210

TRADEMARKS: The trademarks, logos and service marks ("Marks") used herein are the property of Mentor Graphics Corporation or other parties. No one is permitted to use these Marks without the prior written consent of Mentor Graphics or the owner of the Mark, as applicable. The use herein of a third- party Mark is not an attempt to indicate Mentor Graphics as a source of a product, but is intended to indicate a product from, or associated with, a particular third party. A current list of Mentor Graphics' trademarks may be viewed at: www.mentor.com/trademarks.

End-User License Agreement: You can print a copy of the End-User License Agreement from: www.mentor.com/eula.